

- 1) You have to put volt meter on the white wire of JMS Voltage Booster.
- 2) On the dials turn number 1 on. 2 is off. 3 is off. 4 is on. 5 is off. Those are our specs for every car that leaves our shop.
- 3) Two ground wires coming out of PedalMax get touched together with car running. That's when you set your output voltage. Goal is 17.48. Remove two ground wires, shut key off, then key on. Push gas pedal half way. That is how input trigger is set. At that point key on voltage goes to 17.48.
- 4) Hit switch 1 off all settings are saved. Tape off the two ground wires so they can not touch each other.